





Art No. FM0001A

FM Transmitter + MP3 Player

Specification:

- Supports SD cards and has one USB and Audio interface to connect MP3 and MP4 devices
- Supports MP3 and WMA format
- Reads files from SD card and USB interface directly
- LED Display; shows frequency information
- Full frequency range (87.5 108 MHz)
- Saves frequency and music title
- Secure transmitter power and frequency transfer
- Rotatable axis for easy use
- Modern and stylish design
- Device starts with the last saved parameter for frequency, volume and title number
- Supports SD card up to 16GB.

20 Keys Remote Control:

CH - CH -	(CH +) (Vol +) (Market) (Marke
7 8 Pick Song LogiLin	9 CH Set) nk _®

Play / Pause	Start / Stop the music	
CH (-) / CH (+)	Frequency down / Frequency up	
EQ	8 Models to change the sound characteristics:	
	E1: NORMAL (Default setting), E2: ROCK, E3:	
	POP, E4: CLASSIC, E5: SOFT, E6: JAZZ, E7:	
	DBB, E8: SRS	
Volume (-)	Volume down	
Volume (+)	Volume up	
PREV	Previous track	
NEXT	Next track	
0123456789	Number keys for setting the frequency &	
	picking songs	
Pick Song	Confirms picking a song after selection with	
	the number keys	
CH Set	Confims setting the frequency after selection	
	with the number keys	









Art No. FM0001A

FM Transmitter + MP3 Player

Overview:

- 1. FM Frequency Choose
- 2. Play / Pause
- 3. Previous / Volume "-"
- 4. Next / Volume "+"
- 5. LED Display
- 6. Audio output Jack
- 7. SD Card
- 8. Connect to USB Flash or USB Card Reader

Logiline 7

Package Contents

- 1 x FM Transmitter
- 1 x Remote Control
- 1 x Audio Cable
- 1 x User Manual

Positive Pole Negative Pole USB Jack SD Card Jack

Packaging Information:

• Packing Dimension: 157x198x87 mm

• Packing Weight: 0.15kg

• Carton Dimension: 470x290x340 mm

Carton Q'ty: 20pcsCarton Weight: 3.6kgs











^{*} The specifications and pictures are subject to change without notice. *All trade names referenced are the registered namework of their respective owners.